CLEANING SOLUTIONS

B-Clean by Bollé Safety is a complete and efficient cleaning solutions range. Silicone free, its aqua formula guarantees perfect cleaning and protection for your glasses and goggles.



Cleaning Sprays







B411 PACS250

Anti-fog Sprays



B412 PACS050

Wipes & Tissues







B100 PACW100

B401 PACMPCT

Dispensers



B200 PACF030



B250 PACF500



B300 PACFAR3



B600 PACD500



B410 PACD250

- **+** AQUA FORMULA
- **#** SILICONE FREE
- **★** FOR ALL TYPES OF LENSES*
 (* EXCEPT AR COATED LENSES FOR THE PACF030 & PACF500 VERSIONS)



CLEANING SOLUTIONS

PRODUCT	REF.	DESCRIPTION DIMENSIONS IN CM				
Cleaning Sprays						
B402	PACS500	Lens cleaner (spray) 500ml H: 22.5 x Ø: 6,5				
B411	PACS250	Lens cleaner (spray) 250ml	270g			
B412	PACS050	Lens cleaner (spray) 50ml H: 11,3 x Ø: 3,2				
Anti-Fog Sprays						
B250	PACF500	Anti-fog (spray) 500ml	H: 22.5 x Ø: 6,5	540g		
B200	PACF030	Anti-fog kit: 30ml anti-fog solution (spray) + microfiber tissue included	H: 13.5 x L: 5 x P: 3.5	90g		
B300	PACFAR3	Anti-fog kit: 30ml anti-fog solution (spray) + synthetic shammy cloth included	H: 11 x L: 4 x P: 3.5	58g		
Cleaning Wipes & Tissues						
B500	PACW500	500 cleaning premoistened tissues dispenser	H: 22 x L: 27.5 x P: 10.5	1300g		
B100	PACW100	100 cleaning premoistened tissues dispenser	H: 20.5 x L: 12.5 x P: 6	290g		
B401	PACMPCT	200 multi-function dry cleaning tissues for PACD500 & PACD250	H: 12 x L: 16 x P: 5	155g		
Dispensers						
B600	PACD500	Plastic cleaning station with 500ml lens cleaner + 2 x 200 multi-function dry cleaning tissues	H: 34.5 x L: 45 x P: 7.5 1565			
B410	PACD250	Carton cleaning station with 250ml lens cleaner + 2 x 200 multi-function dry cleaning tissues	H: 16.5 x L: 29.5 x P: 5.5	680g		

See user instructions on the next page.

PACKAGING AND EAN 13 CODE											
	PACS500	PACS250	PACS050	PACF500	PACF030	PACFAR3	PACW500	PACW100	PACMPCT	PACD500	PACD250
Per piece	3660740009892	3660740009915	3660740009922	3660740009878	3660740009861	3660740011949	3660740009939	3660740009854	3660740009885	3660740008741	3660740009908
Quantity per inner box	15	25	100	15	10	10	-	25	-	-	10
Quantity per master carton	30	50	200	30	100	100	12	50	36	6	20



Non-contractual pictures

13/05/2021

Bollé Safety AU Pty Limited 32-40 Fairchild Street Heatherton VIC 3202 T: 1300 138 098 E: sales@bollesafety.com.au Hong Kong Bollé Safety 818, 8/F, Ocean Centre, Harbour City, 5 Canton Road, Tsim Sha Tsui, Kowloon, Hong Kong T.: +852 2732 5038



CLEANING SOLUTIONS

USER INSTRUCTIONS

PRODUCT	SKU	USER INSTRUCTION	
Anti-fog	PACF030* PACF500*	Remove the glasses from your face. Spray anti-fog solution on both sides of your glasses and dry it with a microfibre cloth. After applying the anti-fog spray wait 2 minutes before wearing the glasses.	
Anti-Fog	PACFAR3	Remove the glasses from your face. Spray anti-fog solution on both sides of your glasses and dry it using the synthetic shammy cloth. After applying the anti-fog spray wait 2 minutes before wearing the glasses.	
Cleaning Tissues	PACW100 PACW500	Remove the glasses from your face. Unfold a cleaning premoistened tiss and use it to gently clean both sides of your lenses in circular movement until it is dry.	
Cleaning Sprays	PACD250 PACD500 PACS050 PACS250 PACS500	Remove the glasses from your face. Spray cleaning solution on both side your glasses and dry it with a microfibre cloth.	

^{*}Do not use PACF500 & PACF030 on anti-reflect coated equipments.

STORAGE: All products must be stored in a dry and clean environment.



Non-contractual pictures

13/05/2021

Bollé Safety AU Pty Limited 32–40 Fairchild Street Heatherton VIC 3202 T: 1300 138 098 E: sales@bollesafety.com.au



